

www.evotech-performance.com

BMW F 900 R / SE


Installation Instructions


Installation Instructions





Kit Contents PRN015027


- A 1 x Cable Tie
- B 2 x Spacer
- © 2 x Rubber Pad
- D 4 x M4 x 8 Button Head Bolt
- **E** 4 x Rubber Bung
























<u>10</u>








Locate round holes amongst hexagons.

Push Rubber Spacer through from the back of the guard so Hexagonal shape sits on the front face









Repeat Both Sides







Repeat























































It is recommended that periodic inspections are made to ensure that dirt and debris have not become trapped between the guard and the radiator/oil cooler. Such dirt and debris would reduce the cooling efficiency of the radiator/oil cooler.

It is recommended that periodic inspections are made to ensure that all fixings are fully tightend.





www.evotech-performance.com