



#### PREVENCIÓN

- Usar agua y jabón neutro para limpiar la pantalla.
  - Revisar periódicamente el apriete de la tornillería.
  - Estacionar el scooter en dirección al sol, evitando el efecto lupa que puede dañar algunas partes.
  - Aparcar si es posible en superficies niveladas.
- Gracias por su atención.

#### PREVENTION

- Use water and neutral soap to clean the windshield.
- Check the tightening of the fasteners periodically.
- Park the scooter facing the sun, avoiding the sun-reflection effect that may damage some parts.
- Park if possible on even surfaces.

Thanks for your attention.

ID.	DESCRIPCIÓN	DESCRIPTION	QTY.
1	Pantalla transparente	Clear windshield	1
2	Soporte metálico 70x80°xØ8	Metal support 70x80°xØ8	2
3	Manecilla (Regula inclinación pantalla carenabris)	Regulator (adjusts the inclination of the windshield)	2
4	Arandela de plástico	Plastic washer	4
5	Tornillo 5,5x14 para rosca a plástico	5,5x14 screw to tight into plastic	2
6	Soporte con taladro pasante	Support with drill through	2
7	Tornillo con taladro pasante Ø10,5x42	Ø10,5x42 screw with drill through	2
8	Arandela con rebaje R10	Special washer	2
9	Calibrado Ø10x230	Ø10x230 bar	2
10	Caperuza plana M8	M8 nut cover	6
11	Tornillo M8x25	M8x25 screw	2
12	Tornillo 5,5x12 para rosca a plástico	5,5x12 screw to tight into plastic	2
13	Arandela plana M8 DIN 125/A	M8 washer DIN 125/A	6
14	Casquillo Ø8xØ20x6	Arrowhead Ø8xØ20x6	2
15	Casquillo Ø8xØ14x12	Arrowhead Ø8xØ14x12	2
16	Soporte plástico	Plastic support	2
17	Tuerca M8 DIN 6923	M8 nut cover DIN 6923	4
18	Tornillo M8x35 DIN 931	M8x35 screw DIN 931	2
19	Platina (Regula anchura herraje carenabris)	Platen (width adjuster for windshield bracket)	2
20	Fuelle tapa taladro	Bellow drill cover	2
21	Tapón tornillo	Screw cap	4
22	Adaptador hex. rosca ext.izq.M8 a rosca int.M8	Adapter hex. thread ext.left M8 to thread int.M8	2
23	Adaptador hex. rosca ext.M10 a rosca int.M8	Adapter hex. thread ext.M10 to thread int.M8	2
24	Adaptador hex. rosca ext.izq.M10 a rosca int.M8	Adapter hex. thread ext.left M10 to thread int.M8	2
25	Adaptador hex. rosca int.izq.M8 a rosca ext.M8	Adapter hex. thread int.left M8 to thread ext.M8	2
26	Adaptador hex. rosca int.M10 a rosca ext.M8	Adapter hex. thread int.M10 to thread ext.M8	2
27	Adaptador hex. rosca int.izq.M10 a rosca ext.M8	Adapter hex. thread int.left M10 to thread ext.M8	2

## CARENABRÍS ADAPTABLE A - WINDSHIELD ADAPTABLE TO UNIVERSAL

Mod.: TX  
Ref.: 1952

